INSTALLATION INSTRUCTIONS FOR: SEMI-PERMANENT "GOOSE NECK" GOAL POSTS PRODUCT CODES - FGNGPH/FGNGP2Ø TOP PLATE TO BE SET AT 8" BELOW GROUND LEVEL

NOTE: WE RECOMMEND INSTALLATION BE DONE BY A QUALIFIED CONTRACTOR, FAMILIAR WITH ALL CODES, LAWS, REGULATIONS, AND TRACK AND FIELD CONSTRUCTION.

- 1. DETERMINE OFFSET DISTANCE BY MEASURING FROM FRONT OF CROSSBAR TO CENTER OF SUPPORT POST. THIS WILL BE APPROX. 5 FEET. CHECK MEASUREMENT AS BENDS IN PIPE MAY VARY. NOTE PAGE 2.
- 2. MEASURE FROM BACK OF 4" END LINE, DISTANCE DETERMINED IN # 1 THIS WILL CORRESPOND TO THE CENTER OF THE HOLE TO BE DUG.
- 3. DIG HOLES 24" X 24" X 62" DEEP. PLANT GROUND SLEEVE ABSOLUTELY LEVEL AND 11.0" BELOW THE GROUND SURFACE. BE SURE GROUND PLATE IS SQUARE WITH THE FIELD LAYOUT.
- 4. LET CONCRETE SET UP FOR AT LEAST 4 DAYS BEFORE ERECTING GOALS.
- 5. BOLT GOOSENECKS INTO PLACE USING THE STUDS AND NUTS AS SHOWN.

 SOME ADJUSTMENTS CAN BE MADE WITH USE OF THE TWO NUTS BETWEEN THE PLATES.
- 6. (PREFERABLY), USE A HIGH LIFT TO INSERT CROSSBAR INTO END OF GOOSENECK.
 USE A LEVEL ON THE CROSSBAR AND TIGHTEN THE TWO 1/2" X 1" SET SCREW BOLTS LOCATED AT THE SIDES. PAGE 3.
- 7. DRILL OUT TOP AND BOTTOM (NUTS WITH NO THREADS) AND INSTALL THE 1/2" X 6" BOLT AS SHOWN ON PAGE 3.
- 8. INSTALL UPRIGHTS.TIGHTEN SET SCREWS. (3/8" X 1" HEX BOLTS).
- 9. COVER HOLE AROUND THE GOOSENECKS TO BRING IT UP TO THE LEVEL OF THE PLAYING FIELD.

www.stackhouseathletic.com			
-STACKHOUSE	SEMI-PERMANENT GOOSENECK FOOTBALL GOAL POSTS		DATE: 11-08
athletic equipment	INSTALLATION INSTRUCTIONS		DRAWN BY: S.L.
Phone: (503) 363-1840 Toll Free: (800) 285-3604 Fax: (503) 363-0511 www.stackhouseathletic.com	PAGE 1 of 3	PRODUCT CODE: FGNGPH/FGNGP20	DWG: SEMI-PERM INST PG1-REV-Ø8



