INSTALLATION INSTRUCTIONS FOR: PERMANENT "GOOSE NECK" GOAL POSTS

NOTE: WE RECOMMEND INSTALLATION BE DONE BY A QUALIFIED CONTRACTOR, FAMILIAR WITH ALL CODES, LAWS, REGULATIONS, AND TRACK AND FIELD CONSTRUCTION.

- 1. DETERMINE OFFSET DISTANCE BY MEASURING FROM CENTER OF CROSSBAR END OF SUPPORT POST. THIS WILL BE APPROX 5 FT. CHECK MEASUREMENT AS BENDS IN PIPE MAY VARY. NOTE PAGE 2
- 2. MEASURE FROM BACK OF 4" END LINE MEASUREMENT DETERMINED IN #1 ABOVE. THIS WILL CORRESPOND TO THE CENTER OF THE HOLE TO BE DUG.
- 3. DIG HOLE APPROX. 30" X 30" X 60" DEEP.
- 4. PLACE GOOSENECK SUPPORT POST IN HOLE AND BRACE IN A PLUMB AND SQUARE POSITION WITH THE TOP MEASURING 10'-0" TO THE GROUND. (THESE ARE CRITICAL STEPS AND MUST BE DONE CORRECTLY OR GOAL WILL NOT MEET SPECIFICATIONS ON LOCATION).
- 5. WITH POST BRACED IN POSITION, FILL HOLE WITH CONCRETE TO WITHIN 6" OF SURFACE. ALLOW CONCRETE TO CURE A MINIMUM OF 5 DAYS BEFORE REMOVING BRACING.
- 6. WITH THE AID OF A LIFT, RAISE THE CROSSBAR AND INSERT IT INTO THE SUPPORT POST. LEVEL CROSSBAR AND TIGHEN THE 2 SET BOLTS. (1/2 X 1" HEX BOLTS) AT THE SIDES.
- 7. DRILL THRU TOP AND THEN BOTTOM FOR THE 1/2" X 6" HEX BOLTS.
- 8. INSTALL UPRIGHTS. TIGHTEN SET SCREWS.

athletic equipment

www.stackhouseathletic.com

FPGHS - 10 FT STEEL TOP UPRIGHTS FPGC - 20 FT ALUMINUM TOP UPRIGHTS

www.stackhouseathletic.com

Phone: (503) 363-1840 Toll Free: (800) 285-3604

-STACKHOUSE

Fax: (503) 363-0511

_	PERMANENT F	OOTBALL GOOSENECK GOAL POSTS	DATE: 11-08
	INSTALLATION INSTRUCTIONS		DRAWN BY: S.L.
	PAGE 1 of 3	PRODUCT CODE: FPGHS/FPGC	DWG: PERM-INSTALL PG1-REV-08



